

Pop-up Waste Assembly Installation Instructions

Plug and Waste Installation Procedure

1. Disassemble the Rubber Washers and Long Waste Nut, as shown in **Fig. 1**.
2. Apply flexible sealant to the underside face of the Waste Body as shown.
3. Fit Waste Body into basin waste hole and align Waste Overflow to basin overflow slot, as shown in **Fig. 1**.
4. Fit Rubber Washers to the underside of the Waste Body and secure with Long Waste Nut, as detailed in **Fig.1**.

IMPORTANT: DO NOT OVERTIGHTEN.

5. Disassemble the Top Cap from the Pop-up Waste Mechanism as shown in **Fig.1**. The Top Cap assembly can be unscrewed by hand.
6. Wipe away excessive sealant around the flange of the Waste Body.
7. Screw the Top Cap assembly back onto the Pop-up Waste Mechanism. Ensure the Pop-up Waste Assembly is centralised with the basin waste.

Installation must be in accordance with AS/NZS 3500.2 and Plumbing Code of Australia.

