

Cleaners Sink Wall Mounting Legs & Brackets

Suitable for item codes: Y5904 and Y5914

Instruction to install your Cleaners Sink Wall Mounting Legs (pair) and Brackets (pair)

1. Suitable wall mounting brackets Y5904 or Y5914
One pair for heavy duty installations (2 required).
These can be purchased through your plumbing supplier.
2. Draw a level line on the wall at the desired height for the basin top.
Mark width of the sink on the line, on its desired position.
3. Fasten one bracket to the wall so that the top is 1mm below the horizontal line and 1mm inside the sink width mark, from one end.
The bracket should be orientated so bolt holes are vertically aligned and below the basin.
4. Slide unsecured bracket into other side of the basin and then slide the basin onto the fastened bracket. Hold the sink level and mark the bolt holes.
5. Remove the bracket and fasten the remaining bracket to the wall using the marked hole positions. Install waste assemblies and taps if required. It is suggested that silicon sealer be used between the waste grate and basin outside hole.
6. Slide the basin onto the brackets so it is firmly against the wall and secure through the tiling flange.
7. Plumb up the tap and waste fittings.



GWA

Bathrooms & Kitchens

Caroma Industries Limited
ABN 35 000 189 499
1 Melito Court, Prestons NSW 2170
National Customer Call Centre
13 14 16
caroma.com.au



New Zealand
National Customer Call Centre
09 279 2700
caroma.co.nz