



CAROMA

CARAVELLE CROSS - HANDLE ASSEMBLY

+

PLUMBERS INSTALLATION INSTRUCTIONS

Installation

Fit handle assembly as follows:-

- i) Turn both spindles (6) to the fully closed position.
- ii) Place retaining nut (4) over spindle (6), with slot facing flange (7).
- iii) Fit retaining clip (3) into groove at bottom of spline in spindle (6).
- iv) Ensure handle insert (2) is in position in handle (1). Fit handle (1) to spline of spindle, position handle to suit then push firmly down until it bottoms internally. **Note:** Water supplies are indicated by the following handle colours. Blue = Cold, Red = Hot
- v) Screw retaining nut (4) into handle and tighten with spanner (5) provided.

