

INSTALLATION INSTRUCTIONS

- 1) Check that you have selected the correct riser kit, to match the decorative finish on the basin tap.
- 2) Unscrew the clamp ring (6), slide the metal washer (5), flat seal (4) and base ring (2) out over the flexible hose (11), sensor cables (9 & 10) and put them aside. Then by using slight force by hand, unscrew the threaded tube (3) and put it aside.
- 3) Take the riser (8) out of the box, orientate it by keeping the male threaded end at the top as shown in **Fig. 2**, pass it over the flexible tail (11) first then over the sensor cables (9 & 10). Then while taking care of the decorative finish, fit the male threaded end under the tap body, screw it in and hand tighten firmly.
- 4) Screw the threaded tube (3) in the underside of riser (8) until it bottoms and hand tighten.
- 5) Slide the base ring (2) along with 'O'-ring over the threaded tube (3) until the base ring (2) shoulder fully enters the riser (8). Pass the end connection nut of hose (11) into the hole in the deck, followed by sensor cables (9 & 10), then insert threaded tube (3) of tap body (1) into deck hole, locate mixer as required, fit metal washer (5) together with flat seal (4) over the flexible hose (11), over the sensor cables (9 & 10) then the threaded tube as shown in **Fig. 3**. Screw clamp ring (6) onto threaded tube until it contacts washer (5) & the flat seal (4) has contacted the underside of the deck. Tighten two screws (7) equally. **DO NOT OVERTIGHTEN.**

Installation instructions supplied with the sensor basin outlets must be followed to complete the rest of the installation.

